



Communication Protocols

Tiny BMS



Revision D, 2025-07-04

Contents

Chapter 1: <i>Tiny BMS UART</i> communication protocol.....	4
1. Introduction.....	4
1.1. <i>UART</i> communication commands list.....	4
1.1.1. <i>Tiny BMS acknowledgement</i>	4
1.1.2. Read <i>Tiny BMS</i> registers block.....	4
1.1.3. Read <i>Tiny BMS</i> individual registers.....	5
1.1.4. Write <i>Tiny BMS</i> registers block.....	5
1.1.5. Write <i>Tiny BMS</i> individual registers.....	5
1.1.6. Read <i>Tiny BMS</i> registers block (<i>MODBUS</i> compatible).....	6
1.1.7. Write <i>Tiny BMS</i> registers block (<i>MODBUS</i> compatible).....	6
1.1.8. Reset <i>Tiny BMS</i> , clear <i>Events</i> and <i>Statistics</i>	7
1.1.9. Read <i>Tiny BMS</i> newest <i>Events</i>	7
1.1.10. Read <i>Tiny BMS</i> all <i>Events</i>	7
1.1.11. Read battery pack voltage (<i>Reg:36</i>).....	8
1.1.12. Read battery pack current (<i>Reg:38</i>).....	8
1.1.13. Read battery pack max. cell voltage (<i>Reg:41</i>).....	8
1.1.14. Read battery pack min. cell voltage (<i>Reg:40</i>).....	8
1.1.15. Read <i>Tiny BMS</i> online status (<i>Reg:50</i>).....	8
1.1.16. Read <i>Tiny BMS</i> lifetime counter (<i>Reg:32</i>).....	9
1.1.17. Read <i>Tiny BMS</i> estimated SOC value (<i>Reg:46</i>).....	9
1.1.18. Read <i>Tiny BMS</i> device temperatures (<i>Reg:48</i> , <i>Reg:42</i> , <i>Reg:43</i>).....	9
1.1.19. Read battery pack cells voltages.....	10
1.1.20. Read <i>Tiny BMS</i> settings values (min, max, default, current).....	10
1.1.21. Read <i>Tiny BMS</i> version.....	10
1.1.22. Read <i>Tiny BMS</i> extended version.....	10
1.1.23. Read <i>Tiny BMS</i> calculated speed, left distance and estimated time values.....	11
1.2. CRC checksum calculation.....	11
1.3. <i>UART</i> communication examples.....	12
1.3.1. <i>MODBUS</i> write registers example.....	12
1.3.2. <i>MODBUS</i> read registers example.....	13
1.3.3. <i>Tiny BMS</i> read temperatures example.....	13
Chapter 2: <i>Tiny BMS CAN bus</i> communication protocol.....	14
2. Introduction.....	14
2.1. <i>CAN bus</i> communication commands list.....	14
2.1.1. Reset <i>Tiny BMS</i> , clear <i>Events</i> and <i>Statistics</i>	14
2.1.2. Read <i>Tiny BMS</i> registers block.....	14
2.1.3. Write <i>Tiny BMS</i> registers block.....	15
2.1.4. Read <i>Tiny BMS</i> newest <i>Events</i>	15
2.1.5. Read <i>Tiny BMS</i> all <i>Events</i>	16
2.1.6. Read battery pack voltage (<i>Reg:36</i>).....	17
2.1.7. Read battery pack current (<i>Reg:38</i>).....	17
2.1.8. Read battery pack max. cell voltage (<i>Reg:41</i>).....	17
2.1.9. Read battery pack min. cell voltage (<i>Reg:40</i>).....	18
2.1.10. Read <i>Tiny BMS</i> online status (<i>Reg:50</i>).....	18
2.1.11. Read <i>Tiny BMS</i> lifetime counter (<i>Reg:32</i>).....	18
2.1.12. Read <i>Tiny BMS</i> estimated SOC value (<i>Reg:46</i>).....	19
2.1.13. Read <i>Tiny BMS</i> device temperatures (<i>Reg:48</i> , <i>Reg:42</i> , <i>Reg:43</i>).....	19
2.1.14. Read battery pack cells voltages.....	20
2.1.15. Read <i>Tiny BMS</i> settings values (min, max, default, current).....	20
2.1.16. Read <i>Tiny BMS</i> version.....	21
2.1.17. Read <i>Tiny BMS</i> calculated speed, left distance and estimated time values.....	21
2.1.18. Read <i>CAN node ID</i>	22
2.1.19. Write <i>CAN node ID</i>	22
Chapter 3: <i>Tiny BMS</i> registers map.....	23
3. Introduction.....	23

3.1. <i>Tiny BMS Live</i> data.....	23
3.2. <i>Tiny BMS Statistics</i> data.....	23
3.3. <i>Tiny BMS Events</i> data.....	24
3.4. <i>Tiny BMS</i> settings.....	24
3.5. <i>Tiny BMS</i> version data.....	25
Chapter 4: <i>Tiny BMS Events</i> messages list.....	26
4. Introduction.....	26
4.1. <i>Tiny BMS Fault</i> messages list.....	26
4.2. <i>Tiny BMS Warning</i> messages list.....	26
4.3. <i>Tiny BMS Information</i> messages list.....	26

Chapter 1: Tiny BMS UART communication protocol

1. Introduction

Tiny BMS device includes a single multi-purpose *UART* interface. In combination with various converters, the interface is compatible with *USB*, *bluetooth* and *CAN* interfaces. Various proprietary commands are available for fast communication, also *MODBUS* commands *03* and *16* are supported for rapid integration to existing industrial systems. An internal *Tiny BMS* device register map is given in *Chapter 3*. The register map values can be read and modified using *MODBUS* and proprietary commands. This chapter in detail covers all available commands implemented to communicate with *Tiny BMS* device. Every command request and response contains 16 bit *CRC* checksum. How to calculate *CRC* value refer to *Chapter 1.2*.

Note: *UART* configuration: baudrate 115200 bit/s, 8 data bits, 1 stop bit, no parity, no flow control. *UART* configuration is not allowed to be changed by the user.

1.1. *UART* communication commands list

1.1.1. *Tiny BMS* acknowledgement

Response from BMS [NACK]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	CMD	ERROR	CRC:LSB	CRC:MSB
			0x00 – CMD ERROR		
			0x01 – CRC ERROR		

Response from BMS [ACK]				
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
0xAA	0x01	CMD	CRC:LSB	CRC:MSB

CMD – Command code

ERROR – Error code

1.1.2. Read *Tiny BMS* registers block

Request to BMS						
Byte1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0xAA	0x07	RL	ADDR:LSB	ADDR:MSB	CRC:LSB	CRC:MSB
			[UINT_16]			

Response from BMS [OK]									
Byte1	Byte 2	Byte 3	Byte 4	Byte 5	...	Byte n*2+2	Byte n*2+3	Byte n*2+4	Byte n*2+5
0xAA	0x07	PL	DATA1:LSB	DATA1:MSB	...	DATA _n :LSB	DATA _n :MSB	CRC:LSB	CRC:MSB
			[UINT_16]			[UINT_16]			

RL – Registers to read

ADDR – First registers block address

DATA – Registers block values

PL – Payload length byte							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved			Payload size in bytes (last packet)			
1	Reserved			Current packet ID			

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x07	ERROR	CRC:LSB	CRC:MSB

1.1.3. Read Tiny BMS individual registers

Request to BMS										
Byte1	Byte 2	Byte 3	Byte 4	Byte 5	...	Byte n*2+2	Byte n*2+3	Byte n*2+4	Byte n*2+5	
0xAA	0x09	PL	ADDR1:LSB	ADDR1:MSB	...	ADDRn:LSB	ADDRn:MSB	CRC:LSB	CRC:MSB	
			[UINT_16]			[UINT_16]				

PL – Payload length in bytes

Response from BMS [OK]										
Byte1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	...	Byte n*4	Byte n*4+1	
0xAA	0x09	PL	ADDR1:LSB	ADDR1:MSB	DATA1:LSB	DATA1:MSB	...	ADDRn:LSB	ADDRn:MSB	
			[UINT_16]		[UINT_16]			[UINT_16]		
Byte n*4+2	Byte n*4+3	Byte n*4+4	Byte n*4+5							
DATAn:LSB	DATAn:MSB	CRC:LSB	CRC:MSB							
[UINT_16]										

ADDR – Individual registers addresses

DATA – Registers values

PL – Payload length byte							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved						Payload size in bytes (last packet)
1	Reserved						Current packet ID

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x09	ERROR	CRC:LSB	CRC:MSB

1.1.4. Write Tiny BMS registers block

Request to BMS										
Byte1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	...	Byte n*2+4	Byte n*2+5	
0xAA	0x0B	PL	ADDR:LSB	ADDR:MSB	DATA1:LSB	DATA1:MSB	...	DATAn:LSB	DATAn:MSB	
			[UINT_16]		[UINT_16]			[UINT_16]		
Byte n*2+6	Byte n*2+7									
CRC:LSB	CRC:MSB									

ADDR – First registers block address (valid addresses to write 0x012C to 0x018F)

DATA – Registers block values to write

PL – Payload length byte							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved						Payload size in bytes (last packet)
1	Reserved						Current packet ID

Response from BMS [ACK]				
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
0xAA	0x01	0x0B	CRC:LSB	CRC:MSB

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x0B	ERROR	CRC:LSB	CRC:MSB

1.1.5. Write Tiny BMS individual registers

Request to BMS										
Byte1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	...	Byte n*4	Byte n*4+1	
0xAA	0x0D	PL	ADDR1:LSB	ADDR1:MSB	DATA1:LSB	DATA1:MSB	...	ADDRn:LSB	ADDRn:MSB	
			[UINT_16]		[UINT_16]			[UINT_16]		

Byte n*4+2	Byte n*4+3	Byte n*4+4	Byte n*4+5
DATA _n :LSB	DATA _n :MSB	CRC:LSB	CRC:MSB
[UINT_16]			

ADDR – Individual registers addresses (valid addresses to write 0x012C to 0x018F)
DATA – Individual registers values to write

PL – Payload length byte

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Reserved				Payload size in bytes (last packet)		
1	Reserved					Current packet ID	

Response from BMS [ACK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
0xAA	0x01	0x0D	CRC:LSB	CRC:MSB

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x0D	ERROR	CRC:LSB	CRC:MSB

1.1.6. Read Tiny BMS registers block (MODBUS compatible)

Request to BMS

Byte1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xAA	0x03	ADDR1:MSB	ADDR1:LSB	0x00	RL	CRC:LSB	CRC:MSB
[UINT_16]							

ADDR – First registers block address

RL – Registers to read. Max. 127 registers (0x7F)

Response from BMS [OK]

Byte1	Byte 2	Byte 3	Byte 4	Byte 5	...	Byte n*2+2	Byte n*2+3	Byte n*2+4	Byte n*2+5
0xAA	0x03	PL	DATA1:MSB	DATA1:LSB	...	DATA _n :MSB	DATA _n :LSB	CRC:LSB	CRC:MSB
[UINT_16]					[UINT_16]				

PL – Payload length in bytes

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x03	ERROR	CRC:LSB	CRC:MSB

1.1.7. Write Tiny BMS registers block (MODBUS compatible)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte8	Byte 9	...
0xAA	0x10	ADDR:MSB	ADDR:LSB	0x00	RL	PL	DATA1:MSB	DATA1:LSB	...
[UINT_16]					[UINT_16]				

Byte n*2+6	Byte n*2+7	Byte n*2+8	Byte n*2+9
DATA _n :MSB	DATA _n :LSB	CRC:LSB	CRC:MSB
[UINT_16]			

Response from BMS [OK]

Byte1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xAA	0x10	ADDR:MSB	ADDR:LSB	0x00	RL	CRC:LSB	CRC:MSB
[UINT_16]							

ADDR – First registers block address

RL – Registers to write. Max. 100 registers (0x64)

PL – Payload length in bytes

DATA – Registers block values to write

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x10	ERROR	CRC:LSB	CRC:MSB

1.1.8. Reset Tiny BMS, clear Events and Statistics

Request to BMS					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	
0xAA	0x02	OPTION	CRC:LSB	CRC:MSB	
		0x01 – Clear Events			
		0x02 – Clear Statistics			
		0x05 – Reset BMS			

Response from BMS [ACK]				
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
0xAA	0x01	0x02	CRC:LSB	CRC:MSB

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x02	ERROR	CRC:LSB	CRC:MSB

1.1.9. Read Tiny BMS newest Events

Request to BMS			
Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x11	CRC:LSB	CRC:MSB

Response from BMS [OK]											
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	...
0xAA	0x11	PL	BTSP:LSB	BTSP	BTSP	BTSP:MSB	TSP1:LSB	TSP1	TSP1:MSB	EVENT1	...
			[UINT32]				[UINT24]			[UINT_8]	

Byte n*4+4	Byte n*4+5	Byte n*4+6	Byte n*4+7	Byte n*4+8	Byte n*4+9
TSPn:LSB	TSPn	TSPn:MSB	EVENTn	CRC:LSB	CRC:MSB
[UINT_24]			[UINT_8]		

PL – Payload length in bytes

PTSP – BMS timestamp in seconds

TSP – Event timestamp in seconds

EVENT – BMS Event ID

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x11	ERROR	CRC:LSB	CRC:MSB

1.1.10. Read Tiny BMS all Events

Request to BMS			
Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x12	CRC:LSB	CRC:MSB

Response from BMS [OK]											
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	...
0xAA	0x12	PL	BTSP:LSB	BTSP	BTSP	BTSP:MSB	TSP1:LSB	TSP1	TSP1:MSB	EVENT1	...
			[UINT_32]				[UINT_24]			[UINT_8]	

Byte n*4+4	Byte n*4+5	Byte n*4+6	Byte n*4+7	Byte n*4+8	Byte n*4+9
TSPn:LSB	TSPn	TSPn:MSB	EVENTn	CRC:LSB	CRC:MSB
[UINT_24]			[UINT_8]		

PL – Payload length in bytes

PTSP – BMS timestamp in seconds

TSP – Event timestamp in seconds

EVENT – BMS Event ID

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x12	ERROR	CRC:LSB	CRC:MSB

1.1.11. Read battery pack voltage (Reg:36)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x14	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xAA	0x14	DATA:LSB	DATA	DATA	DATA:MSB	CRC:LSB	CRC:MSB
[FLOAT]							

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x14	ERROR	CRC:LSB	CRC:MSB

1.1.12. Read battery pack current (Reg:38)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x15	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xAA	0x15	DATA:LSB	DATA	DATA	DATA:MSB	CRC:LSB	CRC:MSB
[FLOAT]							

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x15	ERROR	CRC:LSB	CRC:MSB

1.1.13. Read battery pack max. cell voltage (Reg:41)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x16	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x16	DATA:LSB	DATA:MSB	CRC:LSB	CRC:MSB
[UINT_16]					

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x16	ERROR	CRC:LSB	CRC:MSB

1.1.14. Read battery pack min. cell voltage (Reg:40)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x17	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x17	DATA:LSB	DATA:MSB	CRC:LSB	CRC:MSB
[UINT_16]					

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x17	ERROR	CRC:LSB	CRC:MSB

1.1.15. Read Tiny BMS online status (Reg:50)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x18	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x18	DATA:LSB	DATA:MSB	CRC:LSB	CRC:MSB
0x91 – Charging [INFO]					
0x92 – Fully Charged [INFO]					
0x93 – Discharging [INFO]					
0x96 – Regeneration [INFO]					
0x97 – Idle [INFO]					
0x9B – Fault [ERROR]					

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x18	ERROR	CRC:LSB	CRC:MSB

1.1.16. Read *Tiny BMS* lifetime counter (Reg:32)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x19	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xAA	0x19	DATA:LSB	DATA	DATA	DATA:MSB	CRC:LSB	CRC:MSB
[UINT_32]							

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x19	ERROR	CRC:LSB	CRC:MSB

1.1.17. Read *Tiny BMS* estimated SOC value (Reg:46)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x1A	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xAA	0x1A	DATA:LSB	DATA	DATA	DATA:MSB	CRC:LSB	CRC:MSB
[UINT_32]							

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x1A	ERROR	CRC:LSB	CRC:MSB

1.1.18. Read *Tiny BMS* device temperatures (Reg:48, Reg:42, Reg:43)

Request to BMS

Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x1B	CRC:LSB	CRC:MSB

Response from BMS [OK]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11
0xAA	0x1B	PL	DATA1:LSB	DATA1:MSB	DATA2:LSB	DATA2:MSB	DATA3:LSB	DATA3:MSB	CRC:LSB	CRC:MSB
[INT_16]										[INT_16]

PL – Payload length in bytes

DATA1 – *Tiny BMS* internal temperature

DATA2 – External temperature sensor #1 temperature value (value of -32768 if not connected)

DATA3 – External temperature sensor #2 temperature value (value of -32768 if not connected)

Response from BMS [ERROR]

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x1B	ERROR	CRC:LSB	CRC:MSB

1.1.19. Read battery pack cells voltages

Request to BMS			
Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x1C	CRC:LSB	CRC:MSB

Response from BMS [OK]									
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	...	Byte n*2+2	Byte n*2+3	Byte n*2+4	Byte n*2+5
0xAA	0x1C	PL	DATA1:LSB	DATA1:MSB	...	DATA n :LSB	DATA n :MSB	CRC:LSB	CRC:MSB
			[UINT_16]				[UINT_16]		

PL – Payload length in bytes

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x1C	ERROR	CRC:LSB	CRC:MSB

1.1.20. Read *Tiny BMS* settings values (min, max, default, current)

Request to BMS						
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0xAA	0x1D	OPTION	0x00	RL	CRC:LSB	CRC:MSB
		0x01 – Min. settings				
		0x02 – Max. settings				
		0x03 – Default settings				
		0x04 – Current settings				

RL – Registers to read. Max. 100 (0x64) registers

Response from BMS [OK]									
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	...	Byte n*2+2	Byte n*2+3	Byte n*2+4	Byte n*2+5
0xAA	0x1D	PL	DATA1:LSB	DATA1:MSB	...	DATA n :LSB	DATA n :MSB	CRC:LSB	CRC:MSB
			[UINT_16]				[UINT_16]		

PL – Payload length in bytes

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x1D	ERROR	CRC:LSB	CRC:MSB

1.1.21. Read *Tiny BMS* version

Request to BMS			
Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x1E	CRC:LSB	CRC:MSB

Response from BMS [OK]									
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10
0xAA	0x1E	PL	DATA1	DATA2	DATA3	DATA4:LSB	DATA4:MSB	CRC:LSB	CRC:MSB
			[UINT_8]	[UINT_8]	[UINT_8]		[UINT_16]		

PL – Payload length in bytes

- DATA1 – Hardware version
- DATA2 – Hardware changes version
- DATA3 – Firmware public version
- DATA4 – Firmware internal version

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x1E	ERROR	CRC:LSB	CRC:MSB

1.1.22. Read *Tiny BMS* extended version

Request to BMS			
Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x1F	CRC:LSB	CRC:MSB

Response from BMS [OK]												
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	Byte 12	
0xAA	0x1F	PL	DATA1	DATA2	DATA3	DATA4:LSB	DATA4:MSB	DATA5	DATA6	CRC:LSB	CRC:MSB	
			[UINT_8]	[UINT_8]	[UINT_8]		[UINT_16]	[UINT_8]	[UINT_8]			

PL – Payload length in bytes

DATA1 – Hardware version

DATA2 – Hardware changes version

DATA3 – Firmware public version

DATA4 – Firmware internal version

DATA5 – Bootloader version

DATA6 – Register map version

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x1F	ERROR	CRC:LSB	CRC:MSB

1.1.23. Read Tiny BMS calculated speed, left distance and estimated time values

Request to BMS			
Byte 1	Byte 2	Byte 3	Byte 4
0xAA	0x20	CRC:LSB	CRC:MSB

Response from BMS [OK]									
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10
0xAA	0x20	DATA1:LSB	DATA1	DATA1	DATA1:MSB	DATA2:LSB	DATA2	DATA2	DATA2:MSB
			[FLOAT]					[UINT_32]	

Byte 11	Byte 12	Byte 13	Byte 14	Byte 15	Byte 16
DATA3:LSB	DATA3	DATA3	DATA3:MSB	CRC:LSB	CRC:MSB
			[UINT_32]		

DATA1 – Speed (km/h)

DATA2 – Left distance to empty battery (km)

DATA3 – Estimated time left to empty battery (seconds)

Response from BMS [ERROR]					
Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0xAA	0x00	0x20	ERROR	CRC:LSB	CRC:MSB

1.2. CRC checksum calculation

CRC stands for *Cyclic Redundancy Check*. It is two bytes added to the end of every command message for error detection. Every byte in the message is used to calculate the *CRC* value. The receiving device also must calculate the *CRC* and compare it to the *CRC* from sending device. If even one bit in the message is received incorrectly, the *CRC* values will be different and will result in an error. In the *Tiny BMS UART* communication protocol the *CRC* checksum is 16 bit value, calculated based on standard *MODBUS CRC* polynomial $x^{16}+x^{15}+x^2+1$ (0x8005 in *HEX* format). Below is the function example in C programming language that can be used as a reference to calculate the 16 bit *CRC* value:

```
const static uint16_t crcTable[256]={
    0x0000, 0xC0C1, 0xC181, 0x0140, 0xC301, 0x03C0, 0x0280, 0xC241,
    0xC601, 0x06C0, 0x0780, 0xC741, 0x0500, 0xC5C1, 0xC481, 0x0440,
    0xCC01, 0x0CC0, 0x0D80, 0xCD41, 0x0F00, 0xCFC1, 0xCE81, 0x0E40,
    0x0A00, 0xCAC1, 0xCB81, 0xB40, 0xC901, 0x09C0, 0x0880, 0xC841,
    0xD801, 0x18C0, 0x1980, 0xD941, 0x1B00, 0DBC1, 0xDA81, 0x1A40,
    0x1E00, 0xDEC1, 0xDF81, 0x1F40, 0xDD01, 0x1DC0, 0x1C80, 0xDC41,
    0x1400, 0xD4C1, 0xD581, 0x1540, 0xD701, 0x17C0, 0x1680, 0xD641,
    0xD201, 0x12C0, 0x1380, 0xD341, 0x1100, 0xD1C1, 0xD081, 0x1040,
    0xF001, 0x30C0, 0x3180, 0xF141, 0x3300, 0xF3C1, 0xF281, 0x3240,
    0x3600, 0xF6C1, 0xF781, 0x3740, 0xF501, 0x35C0, 0x3480, 0xF441,
```

```

0x3C00, 0xFCC1, 0xFD81, 0x3D40, 0xFF01, 0x3FC0, 0x3E80, 0xFE41,
0xFA01, 0x3AC0, 0x3B80, 0xFB41, 0x3900, 0xF9C1, 0xF881, 0x3840,
0x2800, 0xE8C1, 0xE981, 0x2940, 0xEB01, 0x2BC0, 0x2A80, 0xEA41,
0xEE01, 0x2EC0, 0x2F80, 0xEF41, 0x2D00, 0xEDC1, 0xEC81, 0x2C40,
0xE401, 0x24C0, 0x2580, 0xE541, 0x2700, 0xE7C1, 0xE681, 0x2640,
0x2200, 0xE2C1, 0xE381, 0x2340, 0xE101, 0x21C0, 0x2080, 0xE041,
0xA001, 0x60C0, 0x6180, 0xA141, 0x6300, 0xA3C1, 0xA281, 0x6240,
0x6600, 0xA6C1, 0xA781, 0x6740, 0xA501, 0x65C0, 0x6480, 0xA441,
0x6C00, 0xACC1, 0xAD81, 0x6D40, 0xAF01, 0x6FC0, 0x6E80, 0xAE41,
0xAA01, 0x6AC0, 0x6B80, 0xAB41, 0x6900, 0xA9C1, 0xA881, 0x6840,
0x7800, 0xB8C1, 0xB981, 0x7940, 0xBB01, 0x7BC0, 0x7A80, 0xBA41,
0xBE01, 0x7EC0, 0x7F80, 0xBF41, 0x7D00, 0xBDC1, 0xBC81, 0x7C40,
0xB401, 0x74C0, 0x7580, 0xB541, 0x7700, 0xB7C1, 0xB681, 0x7640,
0x7200, 0xB2C1, 0xB381, 0x7340, 0xB101, 0x71C0, 0x7080, 0xB041,
0x5000, 0x90C1, 0x9181, 0x5140, 0x9301, 0x53C0, 0x5280, 0x9241,
0x9601, 0x56C0, 0x5780, 0x9741, 0x5500, 0x95C1, 0x9481, 0x5440,
0x9C01, 0x5CC0, 0x5D80, 0x9D41, 0x5F00, 0x9FC1, 0x9E81, 0x5E40,
0x5A00, 0x9AC1, 0x9B81, 0x5B40, 0x9901, 0x59C0, 0x5880, 0x9841,
0x8801, 0x48C0, 0x4980, 0x8941, 0x4B00, 0x8BC1, 0x8A81, 0x4A40,
0x4E00, 0x8EC1, 0x8F81, 0x4F40, 0x8D01, 0x4DC0, 0x4C80, 0x8C41,
0x4400, 0x84C1, 0x8581, 0x4540, 0x8701, 0x47C0, 0x4680, 0x8641,
0x8201, 0x42C0, 0x4380, 0x8341, 0x4100, 0x81C1, 0x8081, 0x4040
};

uint16_t CRC16 (const uint8_t* data, uint16_t length)
{
    uint8_t tmp;
    uint16_t crcWord = 0xFFFF;

    while (length--)
    {
        tmp = *data++ ^ crcWord;
        crcWord >= 8;
        crcWord ^= crcTable[tmp];
    }
    return crcWord;
}

```

1.3. UART communication examples

Note: If *Tiny BMS* device is in sleep mode, the first command must be send twice. After received the first command *BMS* wakes up from sleep mode, but the response to the command will be sent when it receives the command a second time. *Tiny BMS* does not enter sleep mode again while communication is ongoing.

1.3.1. MODBUS write registers example

Below is an example, how to configure Over-Voltage Cutoff threshold to 4.2 V value and Under-Voltage Cutoff threshold to 2.5 V value using MODBUS write command:

Over-Voltage Cutoff register address is 315 (0x013B)

Under-Voltage Cutoff register address is 316 (0x013C)

According to 1.1.7 chapter:

ADDR = 0x013B (according to *Tiny BMS* registers map);

RL=0x02 (write two registers);

PL=0x04 (all *Tiny BMS* registers contains two bytes);

DATA: 4.2 V=4200 mV (0x1068), 2.5 V=2500 mV (0x09C4);

CRC = 0x6119.

Command request bytes sequence to send to *BMS* according to 1.1.7 chapter:

0xAA 0x10 0x01 0x3B 0x00 0x02 0x04 0x10 0x68 0x09 0xC4 0x19 0x61.

If command was sended successfully, *BMS* responds with data:

0xAA 0x10 0x01 0x3B 0x00 0x02 0x28 0x22

Configured registers block address – 0x013B;

Configurred two registers – 0x0002;

CRC – 0x2228.

1.3.2. MODBUS read registers example

Below is an example, how to read five cells voltages (cell 5 to cell 9) using *MODBUS* read command:

According to 1.1.6 chapter:

ADDR = 0x0005 (cell 5 address according to *Tiny BMS* registers map);

RL=0x05 (read five registers);

CRC = 0x138C.

Command request bytes sequence to send to *BMS* according to 1.1.6 chapter:

0xAA 0x03 0x00 0x05 0x00 0x05 0x8C 0x13.

If command was sent successfully, *BMS* responds with data:

0xAA 0x03 0x0A 0x97 0x40 0x97 0x40 0x97 0x2C 0x97 0x2C 0x97 0x2C 0x3E 0xC7

Payload length – 0x0A (10 bytes);

Cell 5 voltage – 0x9740 (38720 decimal or 3.872 V according to *Tiny BMS* registers map)

Cell 6 voltage – 0x9740 (38720 decimal or 3.872 V according to *Tiny BMS* registers map)

Cell 7 voltage – 0x972C (38700 decimal or 3.870 V according to *Tiny BMS* registers map)

Cell 8 voltage – 0x972C (38700 decimal or 3.870 V according to *Tiny BMS* registers map)

Cell 9 voltage – 0x972C (38700 decimal or 3.870 V according to *Tiny BMS* registers map)

CRC – 0xC73E.

1.3.3. Tiny BMS read temperatures example

Below is provided an example, how to read temperature values using *read Tiny BMS device temperatures* command:

Command request bytes sequence to send to *BMS* according to 1.1.18 chapter:

0xAA 0x1B 0x3F 0x1B

CRC = 0x1B3F.

If command was sent successfully, *BMS* responds with data:

0xAA 0x1B 0x06 0x16 0x01 0x14 0x01 0x16 0x01 0xE 0x4E

Payload length – 0x06 (6 bytes);

Tiny BMS internal temperature – 0x0116 (278 decimal or 27.8 °C according to *Tiny BMS* registers map)

Tiny BMS external #1 temperature – 0x0114 (276 decimal or 27.6 °C according to *Tiny BMS* registers map)

Tiny BMS external #2 temperature – 0x0116 (278 decimal or 27.8 °C according to *Tiny BMS* registers map)

CRC – 0x4E0E.

Chapter 2: Tiny BMS CAN bus communication protocol

2. Introduction

Tiny BMS device used along with *Enepaq CAN-UART* converter module gives an instant CAN bus connectivity with the user side CAN controller or other industrial equipment. Various proprietary commands are available for fast CAN bus communication. This chapter in detail covers all available commands implemented to communicate with *Tiny BMS* device. An internal *Tiny BMS* registers map is given in *Chapter 3*.

Note: CAN bitrate is 500 kbit/s (not allowed to change by the user). Default node *ID* after firmware update is 0x01. When multi-slave CAN bus topology is used, node *ID* can be assigned with 19 *Tiny BMS* CAN command. Automatic node *ID* assignment is not available.

Note: *Tiny BMS CAN-UART* converter works and CAN bus communication is available only when *BMS* device is in active state (charging, discharging or *Ignition* enabled).

2.1. CAN bus communication commands list

2.1.1. Reset *Tiny BMS*, clear Events and Statistics

Request to BMS											8 data bytes*								
CAN identifier 11 bits											8 data bytes*								
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*	
0	1	0	0	0	Node ID (0x01...0x3F)	0x02	OPTION	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	
Default node ID - 0x01											0x01 – Clear Events								
											0x02 – Clear Statistics								
											0x05 – Reset BMS								

* - Last command bytes with zeros can be ignored

Response from BMS [OK]											2 data bytes		
CAN identifier 11 bits											Byte 1	Byte 2	
10	9	8	7	6	5	4	3	2	1	0	0x01	0x02	
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x01	0x02				Default node ID - 0x01	

Response from BMS [ERROR]											3 data bytes		
CAN identifier 11 bits											Byte 1	Byte 2	Byte 3
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	0x02	ERROR				Default node ID - 0x01	

ERROR – Response error code

2.1.2. Read *Tiny BMS* registers block

Request to BMS											8 data bytes*							
CAN identifier 11 bits											8 data bytes*							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	Node ID (0x01...0x3F)	0x03	ADDR:MSB	ADDR:LSB	0x00	RL	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00
Default node ID - 0x01											[UINT_16]							

* - Last command bytes with zeros can be ignored

ADDR – Registers block start addresses

RL – Registers to read. Max. 127 (0x7F) registers

The number of CAN messages responded from *BMS* is equal to the count of registers requested to read. First CAN message returns first register value and each other CAN message returns next registers values respectively.

Response from BMS [OK] – MSG 1										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	Byte 2	Byte 3	Byte 4	Byte 5
Default node ID - 0x01										[UINT_16]
PL						DATA1:MSB	DATA1:LSB	0x00		

Response from BMS [OK] – MSG n										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	Byte 2	Byte 3	Byte 4	Byte 5
Default node ID - 0x01										[UINT_16]
PL						DATAAn:MSB	DATAAn:LSB	n-1		

PL – Payload (DATA) length in bytes

DATA – Registers data

Response from BMS [ERROR]										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	Byte 2	Byte 3	Byte 4	Byte 5
Default node ID - 0x01										[UINT_16]
ERROR										

ERROR – Response error code

2.1.3. Write Tiny BMS registers block

The number of CAN messages sent to BMS is equal to the count of registers requested to write. First CAN message contains start address, register length and first register value and each other CAN message contains next registers values respectively.

Request to BMS – MSG 1										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	Node ID (0x01...0x3F)	0x10	Byte 2	Byte 3	Byte 4	Byte 5
Default node ID - 0x01										[UINT_16]
Byte 1						Byte 6	Byte 7	Byte 8		
ADDR:MSB						RL	DATA1:MSB	DATA1:LSB		

Request to BMS – MSG n												
CAN identifier 11 bits												
10	9	8	7	6	5	4	3	2	1	0		
0	1	0	0	0	Node ID (0x01...0x3F)	0x10	Byte 2	Byte 3	Byte 4	Byte 5		
Default node ID - 0x01										[UINT_16]		
Byte 1						Byte 6	Byte 7	Byte 8				
ADDR:MSB						RL	DATAAn:MSB	DATAAn:LSB				
0x00						n-1						
[UINT_16]												

ADDR - Registers block start addresses. Start address can be in range 0x12C to 0x18F

RL – Registers to write. Max. 100 (0x64) registers

DATA – Registers data to write

Response from BMS [OK]										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	Byte 2	Byte 3	Byte 4	Byte 5
Default node ID - 0x01										[UINT_16]
Byte 1						Byte 6	Byte 7	Byte 8		
ADDR:MSB						RL	DATA1:MSB	DATA1:LSB		
0x00										

ADDR – Configured registers blosck start address

RL – Configured registers

Response from BMS [ERROR]										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	Byte 2	Byte 3	Byte 4	Byte 5
Default node ID - 0x01										[UINT_16]
ERROR										

ERROR – Response error code

2.1.4. Read Tiny BMS newest Events

Request to BMS										
CAN identifier 11 bits										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	Node ID (0x01...0x3F)	0x11	Byte 2*	Byte 3*	Byte 4*	Byte 5*
Default node ID - 0x01										[UINT_16]
Byte 1						Byte 6*	Byte 7*	Byte 8*		
0x00						0x00	0x00	0x00	0x00	0x00

* - Last command bytes with zeros can be ignored

The number of CAN messages responded from BMS is equal to the count of events requested. First CAN message returns current BMS timestamp and each other CAN message returns new event ID and timestamp respectively.

Response from BMS [OK] – MSG 1										
CAN identifier 11 bits										
8 data bytes										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x01	0x11	PL	BTSP:LSB
Default node ID - 0x01						[UINT_32]				
0x00										

Response from BMS [OK] – MSG n										
CAN identifier 11 bits										
8 data bytes										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x01	0x11	PL	TSPn:LSB
Default node ID - 0x01						[UINT_24]				
0x00										[UINT_8]

PL – Payload (DATA) length in bytes

BTSP – Tiny BMS timestamp in seconds

TSP – Newest Event timestamp in seconds

ID – Event ID

Response from BMS [ERROR]										
CAN identifier 11 bits										
3 data bytes										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x00	0x11	ERROR	
Default node ID - 0x01										
0x00										

ERROR – Response error code

2.1.5. Read Tiny BMS all Events

Request to BMS										
CAN identifier 11 bits										
8 data bytes*										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	0	1	Node ID (0x01...0x3F)	0x12	Byte 2*	Byte 3*
Default node ID - 0x01						Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0x00						0x00	0x00	0x00	0x00	0x00

* - Last command bytes with zeros can be ignored

The number of CAN messages responded from BMS is equal to the count of events requested. First CAN message returns current BMS timestamp and each other CAN message returns event ID and timestamp respectively.

Response from BMS [OK] – MSG 1										
CAN identifier 11 bits										
8 data bytes										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x01	0x12	PL	BTSP:LSB
Default node ID - 0x01						[UINT_32]				
0x00										

Response from BMS [OK] – MSG n										
CAN identifier 11 bits										
8 data bytes										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x01	0x12	PL	TSPn:LSB
Default node ID - 0x01						[UINT_24]				
0x00										[UINT_8]

PL – Payload (DATA) length in bytes

BTSP – Tiny BMS timestamp in seconds

TSP – Newest Event timestamp in seconds

ID – Event ID

Response from BMS [ERROR]										
CAN identifier 11 bits										
3 data bytes										
10	9	8	7	6	5	4	3	2	1	0
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x00	0x12	ERROR	
Default node ID - 0x01										
0x00										

ERROR – Response error code

2.1.6. Read battery pack voltage (Reg:36)

Request to BMS											8 data bytes*							
CAN identifier 11 bits											8 data bytes*							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	Node ID (0x01...0x3F)		0x14	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	
Default node ID - 0x01																		

* - Last command bytes with zeros can be ignored

Response from BMS [OK]											6 data bytes						
CAN identifier 11 bits											Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	1	Node ID (0x01...0x3F)		0x01	0x14	DATA:LSB	DATA	DATA	DATA	DATA:MSB				
Default node ID - 0x01																	
[FLOAT]																	

Response from BMS [ERROR]											3 data bytes						
CAN identifier 11 bits											Byte 1	Byte 2	Byte 3				
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3				
0	1	0	0	1	Node ID (0x01...0x3F)		0x00	0x14	ERROR								
Default node ID - 0x01																	

ERROR – Response error code

2.1.7. Read battery pack current (Reg:38)

Request to BMS											8 data bytes*							
CAN identifier 11 bits											Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	Node ID (0x01...0x3F)		0x15	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	
Default node ID - 0x01																		

* - Last command bytes with zeros can be ignored

Response from BMS [OK]											6 data bytes						
CAN identifier 11 bits											Byte 1	Byte 2	Byte 3				
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	1	Node ID (0x01...0x3F)		0x01	0x15	DATA:LSB	DATA	DATA	DATA	DATA:MSB				
Default node ID - 0x01																	
[FLOAT]																	

Response from BMS [ERROR]											3 data bytes						
CAN identifier 11 bits											Byte 1	Byte 2					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3				
0	1	0	0	1	Node ID (0x01...0x3F)		0x00	0x15	ERROR								
Default node ID - 0x01																	

ERROR – Response error code

2.1.8. Read battery pack max. cell voltage (Reg:41)

Request to BMS											8 data bytes*							
CAN identifier 11 bits											Byte 1	Byte 2*						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	Node ID (0x01...0x3F)		0x16	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	
Default node ID - 0x01																		

* - Last command bytes with zeros can be ignored

Response from BMS [OK]											4 data bytes						
CAN identifier 11 bits											Byte 1	Byte 2					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4			
0	1	0	0	1	Node ID (0x01...0x3F)		0x01	0x16	DATA:LSB	DATA:MSB				[UINT_16]			
Default node ID - 0x01																	

Response from BMS [ERROR]

CAN identifier 11 bits											3 data bytes			
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	
0	1	0	0	0	1	Node ID (0x01...0x3F)						0x00	0x16	ERROR

Default node ID - 0x01

ERROR – Response error code

2.1.9. Read battery pack min. cell voltage (Reg:40)

Request to BMS

CAN identifier 11 bits											8 data bytes*								
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*	
0	1	0	0	0	0	1	Node ID (0x01...0x3F)						0x17	0x00	0x00	0x00	0x00	0x00	0x00

Default node ID - 0x01

* - Last command bytes with zeros can be ignored

Response from BMS [OK]

CAN identifier 11 bits											4 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4			
0	1	0	0	0	1	Node ID (0x01...0x3F)						0x01	0x17	DATA:LSB	DATA:MSB	[UINT_16]	

Default node ID - 0x01

ERROR – Response error code

2.1.10. Read Tiny BMS online status (Reg:50)

Request to BMS

CAN identifier 11 bits											8 data bytes*								
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*	
0	1	0	0	0	0	1	Node ID (0x01...0x3F)						0x18	0x00	0x00	0x00	0x00	0x00	0x00

Default node ID - 0x01

* - Last command bytes with zeros can be ignored

Response from BMS [OK]

CAN identifier 11 bits											4 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4			
0	1	0	0	0	1	Node ID (0x01...0x3F)						0x01	0x18	DATA:LSB	DATA:MSB	0x91 – Charging [INFO]	

Default node ID - 0x01

0x92 – Fully charged [INFO]

0x93 – Discharging [INFO]

0x96 – Regeneration [INFO]

0x97 – Idle [INFO]

0x9B – Fault [ERROR]

Response from BMS [ERROR]

CAN identifier 11 bits											3 data bytes			
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	
0	1	0	0	0	1	Node ID (0x01...0x3F)						0x00	0x18	ERROR

Default node ID - 0x01

ERROR – Response error code

2.1.11. Read Tiny BMS lifetime counter (Reg:32)

Request to BMS

CAN identifier 11 bits											8 data bytes*								
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*	
0	1	0	0	0	0	1	Node ID (0x01...0x3F)						0x19	0x00	0x00	0x00	0x00	0x00	0x00

Default node ID - 0x01

* - Last command bytes with zeros can be ignored

Response from BMS [OK]																	
CAN identifier 11 bits											6 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x19	DATA:LSB	DATA	DATA	DATA:MSB						
Default node ID - 0x01											[UINT32]						

Response from BMS [ERROR]																
CAN identifier 11 bits											3 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3			
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	0x19	ERROR								
Default node ID - 0x01											[INT_32]					

ERROR – Response error code

2.1.12. Read Tiny BMS estimated SOC value (Reg:46)

Request to BMS																
CAN identifier 11 bits											8 data bytes*					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*
0	1	0	0	0	Node ID (0x01...0x3F)	0x1A	0x00	0x00	0x00	0x00	Byte 7*	Byte 8*				
Default node ID - 0x01											[0x00]					

* - Last command bytes with zeros can be ignored

Response from BMS [OK]																	
CAN identifier 11 bits											6 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x1A	DATA:LSB	DATA	DATA	DATA:MSB						
Default node ID - 0x01											[UINT32]						

Response from BMS [ERROR]																
CAN identifier 11 bits											3 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3			
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	0x1A	ERROR								
Default node ID - 0x01											[INT_32]					

ERROR – Response error code

2.1.13. Read Tiny BMS device temperatures (Reg:48, Reg:42, Reg:43)

Request to BMS																
CAN identifier 11 bits											8 data bytes*					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*
0	1	0	0	0	Node ID (0x01...0x3F)	0x1B	0x00	0x00	0x00	0x00	Byte 7*	Byte 8*				
Default node ID - 0x01											[0x00]					

* - Last command bytes with zeros can be ignored

Response from BMS [OK] – MSG 1																
CAN identifier 11 bits											6 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x1B	PL	DATA1:LSB	DATA1:MSB	0x00					
Default node ID - 0x01											[INT_16]					

Response from BMS [OK] – MSG 2																
CAN identifier 11 bits											6 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x1B	PL	DATA2:LSB	DATA2:MSB	0x01					
Default node ID - 0x01											[INT_16]					

Response from BMS [OK] – MSG 3																
CAN identifier 11 bits											6 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x1B	PL	DATA3:LSB	DATA3:MSB	0x02					
Default node ID - 0x01											[INT_16]					

PL – Payload (DATA) length in bytes

DATA1 – *Tiny BMS* internal temperature

DATA2 – External temperature sensor #1 temperature value (value of -32768 if not connected)

DATA3 – External temperature sensor #2 temperature value (value of -32768 if not connected)

Response from BMS [ERROR]													
CAN identifier 11 bits											3 data bytes		
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	0	1	Node ID (0x01...0x3F)				0x00	0x1B	ERROR	
Default node ID - 0x01													

ERROR – Response error code

2.1.14. Read battery pack cells voltages

Request to BMS											8 data bytes*							
CAN identifier 11 bits											8 data bytes*							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	0	Node ID (0x01...0x3F)				0x1C	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00
Default node ID - 0x01																		

* - Last command bytes with zeros can be ignored

BMS response returned CAN messages are equal to battery cells count. First CAN message returns first cell voltage and each other CAN message returns next cells voltages respectively.

Response from BMS [OK] – MSG 1											6 data bytes						
CAN identifier 11 bits											6 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	0	1	Node ID (0x01...0x3F)				0x01	0x1C	PL	DATA1:LSB	DATA1:MSB	0x00		
Default node ID - 0x01																	

Response from BMS [OK] – MSG n											6 data bytes						
CAN identifier 11 bits											6 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	0	1	Node ID (0x01...0x3F)				0x01	0x1C	PL	DATA _n :LSB	DATA _n :MSB	n-1		
Default node ID - 0x01																	

PL – Payload (DATA) length in bytes

Response from BMS [ERROR]											3 data bytes						
CAN identifier 11 bits											3 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3				
0	1	0	0	0	1	Node ID (0x01...0x3F)				0x00	0x1C	ERROR					
Default node ID - 0x01																	

ERROR – Response error code

2.1.15. Read *Tiny BMS* settings values (min, max, default, current)

Request to BMS											8 data bytes*							
CAN identifier 11 bits											8 data bytes*							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	0	Node ID (0x01...0x3F)				0x1D	OPTION		0x00	RL	0x00	0x00	0x00	0x00
Default node ID - 0x01																		

* - Last command bytes with zeros can be ignored

RL – Registers to read. Max. 100 (0x64) registers

The number of CAN messages responded from BMS is equal to the count of settings registers requested. First CAN message returns first register and each other CAN message returns next registers respectively.

Response from BMS [OK] – MSG 1											6 data bytes						
CAN identifier 11 bits											6 data bytes						
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	
0	1	0	0	0	1	Node ID (0x01...0x3F)				0x01	0x1D	PL	DATA1:LSB	DATA1:MSB	0x00		
Default node ID - 0x01																	

Response from BMS [OK] – MSG n																
CAN identifier 11 bits											6 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x1D	PL	DATA _n :LSB	DATA _n :MSB	n-1					
Default node ID - 0x01											[UINT_16]					

PL – Payload (DATA) length in bytes

Response from BMS [ERROR]																
CAN identifier 11 bits											3 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3			
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	0x1D	ERROR								
Default node ID - 0x01											[UINT_16]					

ERROR – Response error code

2.1.16. Read Tiny BMS version

Request to BMS																
CAN identifier 11 bits											8 data bytes*					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*
0	1	0	0	0	Node ID (0x01...0x3F)	0x1E	0x00	0x00	0x00	0x00	Byte 7*	Byte 8*				
Default node ID - 0x01											[UINT_8]					

* - Last command bytes with zeros can be ignored

Response from BMS [OK]																
CAN identifier 11 bits											8 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x1E	PL	DATA1	DATA2	DATA3	DATA4:LSB	DATA4:MSB			
Default node ID - 0x01											[UINT_8]					

PL – Payload (DATA) length in bytes

DATA1 – Hardware version

DATA2 – Hardware changes version

DATA3 – Firmware public version

DATA4 – Firmware internal version

Response from BMS [ERROR]																
CAN identifier 11 bits											3 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3			
0	1	0	0	1	Node ID (0x01...0x3F)	0x00	0x1E	ERROR								
Default node ID - 0x01											[UINT_8]					

ERROR – Response error code

2.1.17. Read Tiny BMS calculated speed, left distance and estimated time values

Request to BMS																
CAN identifier 11 bits											8 data bytes*					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*
0	1	0	0	0	Node ID (0x01...0x3F)	0x20	0x00	0x00	0x00	0x00	Byte 7*	Byte 8*				
Default node ID - 0x01											[UINT_8]					

* - Last command bytes with zeros can be ignored

Response from BMS [OK] – MSG 1																
CAN identifier 11 bits											8 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x20	PL	DATA1:LSB	DATA1	DATA1	DATA1:MSB	0x00			
Default node ID - 0x01											[FLOAT]					

Response from BMS [OK] – MSG 2																
CAN identifier 11 bits											8 data bytes					
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0	1	0	0	1	Node ID (0x01...0x3F)	0x01	0x20	PL	DATA2:LSB	DATA2	DATA2	DATA2:MSB	0x01			
Default node ID - 0x01											[UINT_32]					

Response from BMS [OK] – MSG 3

CAN identifier 11 bits											8 data bytes							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x01	0x20	PL	DATA3:LSB	DATA3	DATA3	DATA3:MSB	0x02				

Default node ID - 0x01

[UINT_32]

PL – Payload length in bytes

DATA1 – Speed (km/h)

DATA2 – Left distance to empty battery (km)

DATA3 – Estimated time left to empty battery (seconds)

Response from BMS [ERROR]

CAN identifier 11 bits											3 data bytes		
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x00	0x20	ERROR				

Default node ID - 0x01

ERROR – Response error code

2.1.18. Read CAN node ID

Request to BMS

CAN identifier 11 bits											8 data bytes*							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2*	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	0	0	0	0	0	0	0x28	0x00						

* - Last command bytes with zeros can be ignored

Response from BMS [OK]

CAN identifier 11 bits											3 data bytes		
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x01	0x28	DATA				

Default node ID - 0x01

DATA – CAN-UART converter CAN node ID (0x01 to 0x3F)

Response from BMS [ERROR]

CAN identifier 11 bits											3 data bytes		
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	0	1	Node ID (0x01...0x3F)	0x00	0x28	ERROR				

Default node ID - 0x01

ERROR – Response error code

2.1.19. Write CAN node ID

Request to BMS

CAN identifier 11 bits											8 data bytes*							
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3*	Byte 4*	Byte 5*	Byte 6*	Byte 7*	Byte 8*
0	1	0	0	0	0	Old ID (0x01...0x3F)	0x29	DATA	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00	

* - Last command bytes with zeros can be ignored

DATA - CAN-UART converter CAN node new ID (0x01 to 0x3F)

Response from BMS [OK]

CAN identifier 11 bits											3 data bytes		
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	0	1	New ID (0x01...0x3F)	0x01	0x29	DATA				

Default node ID - 0x01

DATA – CAN-UART converter CAN node new ID (0x01 to 0x3F)

Response from BMS [ERROR]

CAN identifier 11 bits											3 data bytes		
10	9	8	7	6	5	4	3	2	1	0	Byte 1	Byte 2	Byte 3
0	1	0	0	0	1	New ID (0x01...0x3F)	0x00	0x28	ERROR				

ERROR – Response error code

Chapter 3: *Tiny BMS registers map*

3. Introduction

This chapter in detail covers all an internal *Tiny BMS* registers map.

3.1. *Tiny BMS Live data*

Reg. Nr.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Action
0	Cell 1 Voltage [UINT_16] / Resolution 0.1 mV															R	
1	Cell 2 Voltage [UINT_16] / Resolution 0.1 mV															R	
2	Cell 3 Voltage [UINT_16] / Resolution 0.1 mV															R	
3	Cell 4 Voltage [UINT_16] / Resolution 0.1 mV															R	
4	Cell 5 Voltage [UINT_16] / Resolution 0.1 mV															R	
5	Cell 6 Voltage [UINT_16] / Resolution 0.1 mV															R	
6	Cell 7 Voltage [UINT_16] / Resolution 0.1 mV															R	
7	Cell 8 Voltage [UINT_16] / Resolution 0.1 mV															R	
8	Cell 9 Voltage [UINT_16] / Resolution 0.1 mV															R	
9	Cell 10 Voltage [UINT_16] / Resolution 0.1 mV															R	
10	Cell 11 Voltage [UINT_16] / Resolution 0.1 mV															R	
11	Cell 12 Voltage [UINT_16] / Resolution 0.1 mV															R	
12	Cell 13 Voltage [UINT_16] / Resolution 0.1 mV															R	
13	Cell 14 Voltage [UINT_16] / Resolution 0.1 mV															R	
14	Cell 15 Voltage [UINT_16] / Resolution 0.1 mV															R	
15	Cell 16 Voltage [UINT_16] / Resolution 0.1 mV															R	
16-31	Reserved															R	
32	BMS Lifetime Counter [UINT_32] / Resolution 1 s															R	
33																R	
34	Estimated Time Left [UINT_32] / Resolution 1 s															R	
35																R	
36	Battery Pack Voltage [FLOAT] / Resolution 1 V															R	
37																R	
38	Battery Pack Current [FLOAT] / Resolution 1 A															R	
39																R	
40	Minimal Cell Voltage [UINT_16] / Resolution 1 mV															R	
41	Maximal Cell Voltage [UINT_16] / Resolution 1 mV															R	
42	External Temp. Sensor #1 Temperature [INT_16] / Resolution 0.1 °C															R	
43	External Temp. Sensor #2 Temperature [INT_16] / Resolution 0.1 °C															R	
44	Distance Left To Empty Battery [UINT_16] / Resolution 1 km															R	
45	State Of Health [UINT_16] [0 to 50000] / Resolution 0.002 %															R	
46	State Of Charge [UINT_32] / Resolution 0.000001 %															R	
47																R	
48	BMS Internal Temperature [INT_16] / Resolution 0.1 °C															R	
49	Reserved															R	
50	BMS Online Status [UINT_16] / 0x91-Charging, 0x92-Fully Charged, 0x93-Discharging, 0x96-Regeneration, 0x97-IDLE, 0x9B-Fault															R	
51	Balancing Decision Bits [UINT_16] / First Cell - LSB Bit of LSB Byte: 1 - need balancing, 0 - cell no need balance															R	
52	Real Balancing Bits [UINT_16] / First Cell - LSB Bit of LSB Byte: 1 - balancing, 0 – not balancing															R	
53	Number Of Detected Cells [UINT_16]															R	
54	Speed [FLOAT] km/h															R	
55																R	
56-99	Reserved															R	

3.2. *Tiny BMS Statistics data*

Reg. Nr.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Action
100	Total Distance [UINT_32] / Resolution 0.01 km															R	
101																R	
102	Maximal Discharge Current [UINT_16] / Resolution 100 mA															R	
103	Maximal Charge Current [UINT_16] / Resolution 100 mA															R	
104	Maximal Cell Voltage Difference [UINT_16] / Resolution 0.1 mV															R	
105	Under-Voltage Protection Count [UINT_16] / Resolution 1 count															R	
106	Over-Voltage Protection Count [UINT_16] / Resolution 1 count															R	

107	Discharge Over-Current Protection Count [UINT_16] / Resolution 1 count														R							
108	Charge Over-Current Protection Count [UINT_16] / Resolution 1 count														R							
109	Over-Heat Protection Count [UINT_16] / Resolution 1 count														R							
110	Reserved														R							
111	Charging Count [UINT_16] / Resolution 1 count														R							
112	Full Charge Count [UINT_16] / Resolution 1 count														R							
113	Min. Pack Temperature [INT_8] / Resolution 1 °C							Max. Pack Temperature [INT_8] / Resolution 1 °C							R							
114	Last BMS Reset Event [UINT_8] / 0x00-Unknown, 0x01-Low power reset, 0x02-Window watchdog reset, 0x03-Independent watchdog reset, 0x04-Software reset, 0x05-POR/PDR reset, 0x06-PIN reset, 0x07-Options bytes loading reset							Last Wakeup From BMS Sleep Mode Event [UINT_8] / 0x00-Charger connected, 0x01-Ignition, 0x02-Discharging detected, 0x03-UART communication detected							R							
115	Reserved														R							
116	Statistics Last Cleared On Tstamp [UINT_32] / Resolution 1s														R							
117	Reserved														R							
118-199	Reserved														R							

3.3. Tiny BMS Events data

Reg. Nr.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Action							
200	Event_0 Timestamp [UINT_24 LSB] / Resolution 1 s															R								
201	Event_0 Timestamp [UINT_24 MSB] / Resolution 1 s							Event_0 Message ID* [UINT_8]								R								
202	Event_1 Timestamp [UINT_24 LSB] / Resolution 1 s															R								
203	Event_1 Timestamp [UINT_24 MSB] / Resolution 1 s							Event_1 Message ID* [UINT_8]								R								
204	Event_2 Timestamp [UINT_24 LSB] / Resolution 1 s															R								
205	Event_2 Timestamp [UINT_24 MSB] / Resolution 1 s							Event_2 Message ID* [UINT_8]								R								
206	Event_3 Timestamp [UINT_24 LSB] / Resolution 1 s															R								
207	Event_3 Timestamp [UINT_24 MSB] / Resolution 1 s							Event_3 Message ID* [UINT_8]								R								
...								
...								
296	Event_48 Timestamp [UINT_24 LSB] / Resolution 1 s															R								
297	Event_48 Timestamp [UINT_24 MSB] / Resolution 1 s							Event_48 Message ID* [UINT_8]								R								
298	Reserved															R								
299	Reserved															R								

* - Events messages ID list is attached in the Chapter 4.

3.4. Tiny BMS settings

Reg. Nr.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Action
300	Fully Charged Voltage [UINT_16] [1200 to 4500] / Resolution 1 mV															R/W	
301	Fully Discharged Voltage [UINT_16] [1000 to 3500] / Resolution 1 mV															R/W	
302	Reserved															R/W	
303	Early Balancing Threshold [UINT_16] [1000 to 4500] / Resolution 1 mV															R/W	
304	Charge Finished Current [UINT_16] [100 to 5000]* / Resolution 1 mA															R/W	
305	Peak Discharge Current Cutoff [UINT_16] / Resolution 1 A															R/W	
306	Battery Capacity [UINT_16] [10 to 65500] / Resolution 0.01 Ah															R/W	
307	Number Of Series Cells [UINT_16] [4 to 16] / Resolution 1 cell count															R/W	
308	Allowed Disbalance [UINT_16] [15 to 100] / Resolution 1 mV															R/W	
309	Reserved															R/W	
310	Charger Startup Delay [UINT_16] [5 to 60] / Resolution 1 sec.															R/W	
311	Charger Disable Delay [UINT_16] [0 to 60] / Resolution 1 sec.															R/W	
312	Pulses Per Unit [UINT_32] [1 to 100000] / Resolution 1 pulse per unit															R/W	
313	Distance Unit Name [UINT_16] / 0x01-Meter, 0x02-Kilometer, 0x03-Feet, 0x04-Mile, 0x05-Yard															R/W	
315	Over-Voltage Cutoff [UINT_16] [1200 to 4500] / Resolution 1 mV															R/W	
316	Under-Voltage Cutoff [UINT_16] [800 to 3500] / Resolution 1 mV															R/W	
317	Discharge Over-Current Cutoff [UINT_16] [1 to 750]* / Resolution 1 A															R/W	
318	Charge Over-Current Cutoff [UINT_16] [1 to 750]* / Resolution 1 A															R/W	
319	Over-Heat Cutoff [INT_16] [+20 to +90] / Resolution 1 °C															R/W	
320	Low Temperature Charger Cutoff [INT_16] [-40 to +10] / Resolution 1 °C															R/W	
321	Charge Restart Level [UINT_16] [60-95] / Resolution 1 %															R/W	
322	Battery Maximum Cycles Count [UINT_16] [10-65000]															R/W	
323	State Of Health [UINT_16] [0 to 50000] / Resolution 0.002 % / [0xFFFF – when data internally accepted]															R/W	
324	Reserved															R/W	
325	Reserved															R/W	

326	Reserved				R/W
327	Reserved				R/W
328	State Of Charge [UINT_16] [0 to 50000] / Resolution 0.002 %				R/W
329	Invert External Current Sensor Direction [1st bit] (0-1)	Disable Load/Charger Switch Diagnostics [2nd bit] (0-1)	Enable Charger Restart Level [3rd bit] (0-1)	Reserved(13 Bits)	R/W
330	Charger Type [8 bits LSB] / 0x00-Variable (Reserved), 0x01-CC/CV, 0x02-CAN (Reserved) Discharge Over-Current Cutoff Timeout[8 bits LSB] [0-30]/Resolution 1 s				R/W
331	Load Switch Type [8 bits LSB] / 0x00-FET, 0x01-AIDO1, 0x02-AIDO2, 0x03-DIDO1, 0x04-DIDO2, 0x05-AIHO1 Active Low, 0x06-AIHO1 Active High, 0x07-AIHO2 Active Low, 0x08-AIHO2 Active High Reserved				R/W
332	Automatic Recovery [8 bits LSB] [1 to 30] / Resolution 1 s Reserved				R/W
333	Charger Switch Type [8 bits LSB] / 0x01-Charge FET, 0x02-AIDO1, 0x03-AIDO2, 0x04-DIDO1, 0x05-DIDO2, 0x06-AIHO1 Active Low, 0x07-AIHO1 Active High, 0x08-AIHO2 Active Low, 0x09-AIHO2 Active High Reserved				R/W
334	Ignition [8 bits LSB] / 0x00-Disabled, 0x01-AID01, 0x02-AIDO2, 0x03-DIDO1, 0x04-DIDO2, 0x05-AIHO1, 0x06-AIHO2 Reserved				R/W
335	Charger Detection [8 bits LSB] / 0x01-Internal, 0x02-AIDO1, 0x03-AIDO2, 0x04-DIDO1, 0x05-DIDO2, 0x06-AIHO1, 0x07-AIHO2 Reserved				R/W
336	Speed Sensor Input [8 bits LSB] / 0x00-Disabled, 0x01-DIDO1, 0x02-DIDO2 Reserved				R/W
337	Precharge Pin [8 bits LSB] / 0x00-Disabled, 0x02-Discharge FET, 0x03-AIDO1, 0x04-AIDO2, 0x05-DIDO1, 0x06-DIDO2, 0x07-AIHO1 Active low, 0x08-AIHO1 Active high, 0x09-AIHO2 Active low, 0x10-AIHO2 Active high Reserved				R/W
338	Precharge Duration [8 bits LSB] / 0x00-0.1 sec., 0x01-0.2 sec., 0x02-0.5 sec., 0x03-1 sec., 0x04-2 sec., 0x05-3 sec., 0x06-4 sec., 0x07-5 sec. Reserved				R/W
339	Temperature Sensor Type [8 bits LSB] / 0x00-Dual 10K NTC, 0x01-Multipoint Active Sensor Reserved				R/W
340	BMS Operation Mode [8 bits LSB] / 0x00-Dual Port Operation, 0x01-Single Port Operation Reserved				R/W
341	Single Port Switch Type [8 bits LSB] / 0x00-FET, 0x01-AIDO1, 0x02-AIDO2, 0x03-DIDO1, 0x04-DIDO2, 0x05-AIHO1 Active Low, 0x06-AIHO1 Active High, 0x07-AIHO2 Active Low, 0x08-AIHO2 Active High Reserved				R/W
342	Broadcast Time [8 bits LSB] / 0x00-Disabled, 0x01-0.1 sec., 0x02-0.2 sec., 0x03-0.5 sec., 0x04-1 sec., 0x05-2 sec., 0x06-5 sec., 0x07-10 sec. Reserved				R/W
343	Protocol [8 bits LSB] / 0x00-CA V3, 0x01-ASCII, 0x02-SOC BAR Reserved				R/W
344-399	Reserved				R/W

* Tiny BMS device internally changes these settings min. and max. values according to current sensor used.

3.5. Tiny BMS version data

Reg. Nr.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Action						
500	Hardware Version [8 bits LSB]							Hardware Changes Version [8 bits MSB]							R								
501	Public Release Firmware Version [8 bits LSB]							BPT (1 bit)*BCS (2 bits)**	Reserved							R							
502	Internal Firmware Version [UINT_16]															R							
503	Bootloader Version [8 bits LSB]							Profile Version [8 bits MSB]							R								
504	Product Serial Number [96 bits]															R							
505																R							
506																R							
507																R							
508																R							
509																R							
510-599	Reserved																						

* BPT – BMS Power Type / 0x00-Low Power, 0x01-High Power

** BCS – BMS Current Sensor Used / 0x00-Internal Resistor, 0x01-Internal HALL, 0x02-External

Chapter 4: *Tiny BMS Events* messages list

4. Introduction

This chapter in detail covers all the *Tiny BMS Events* messages and its *IDs*.

4.1. *Tiny BMS Fault* messages list

Fault ID (0x01 to 0x30)	Fault message
0x02	Under-Voltage Cutoff Occurred
0x03	Over-Voltage Cutoff Occurred
0x04	Over-Temperature Cutoff Occurred
0x05	Discharging Over-Current Cutoff Occurred
0x06	Charging Over-Current Cutoff Occurred
0x07	Regeneration Over-Current Cutoff Occurred
0x0A	Low Temperature Cutoff Occurred
0x0B	Charger Switch Error Detected
0x0C	Load Switch Error Detected
0x0D	Single Port Switch Error Detected
0x0E	External Current Sensor Disconnected (BMS restart required)
0x0F	External Current Sensor Connected (BMS restart required)

4.2. *Tiny BMS Warning* messages list

Warning ID (0x31 to 0x60)	Warning message
0x31	Fully Discharged Cutoff Occurred
0x37	Low Temperature Charging Cutoff Occurred
0x38	Charging Done (Charger voltage too high)
0x39	Charging Done (Charger voltage too low)

4.3. *Tiny BMS Information* messages list

Info ID (0x61 to 0x90)	Info message
0x61	System Started
0x62	Charging Started
0x63	Charging Done
0x64	Charger Connected
0x65	Charger Disconnected
0x66	Dual Port Operation Mode Activated
0x67	Single Port Operation Mode Activated
0x73	Recovered From Over-Temperature Fault Condition
0x74	Recovered From Low Temperature Warning Condition
0x75	Recovered From Low Temperature Fault Condition
0x76	Recovered From Charging Over-Current Fault Condition
0x77	Recovered From Discharging Over-Current Fault Condition
0x78	Recovered From Regeneration Over-Current Fault Condition
0x79	Recovered From Over-Voltage Fault Condition
0x7A	Recovered From Fully Discharged Voltage Warning Condition
0x7B	Recovered From Under-Voltage Fault Condition
0x7C	External Current Sensor Connected
0x7D	External Current Sensor Disconnected

Revision	Date	Description
A	2018-07-30	Initial release.
B	2018-12-11	Fixed <i>UART command: 1.1.23 Read Tiny BMS calculated speed, left distance and estimated time values.</i>
C	2022-03-24	Company rebranded to Enepaq.
D	2025-07-04	Updated TinyBMS internal register map to reflect latest FW changes: - SOH estimation. - Discharge Over-Current Cutoff. - Discharge Over-Current Cutoff Timeout. - Discharge Peak-Current Cutoff. - Charge Restart Level. - Charger Startup Delay. - Charger Disable Delay.